

instructions wallpaper

Design: Studio Ditte



Made in Holland

www.studioditte.nl

You need

- "Perfax roll" glue (non-woven wallpaper)
- Glue roller
- Seam roller
- Wallpaper ruler
- Boxcutter
- Soft cloth

Instructions

1. Apply the glue directly to the wall. Apply approx. 15 cm more glue than the width of one strip on wallpaper. That way you prevent the glue roller to touch already applied wallpaper.

In case of a wooden wall, it is better to glue the wallpaper instead of the wall. Otherwise, the surface might absorb the glue too quickly.

2. Apply the wallpaper directly to the wall. The strips must be glued tightly together. Use a soft cloth to smooth the wallpaper. To press the seams you can use a seam roller.

3. Cut the wallpaper to size. This is best done with a wallpaper ruler and a boxcutter.

4. Wipe all remainders of glue from the wallpaper with a damp cloth, before the glue dries.

Enjoy your Studio Ditte wallpaper.